


XT270

Part Illustrations



#	Part number	Description	Qty	
1	100031627-0001	Stud, M6×61	1	
2	100002321	Valve Cover	1	1611-002321
3	100005150	Clamp	1	
4	100002859	Breather Hose	1	
5	100010183	Gasket, Valve Cover	1	1611-009022
6	100004426	Rocker Arm Assembly	2	1603-015400
7	100004474	Rocker Arm Base	1	1603-015406
8	100004589	Valve Adjust Cap, Exhaust	1	1603-015713
9	100004586	Valve Spring Seat	1	1603-015711
10	100004584	Valve Spring Seat	1	1603-015712
11	100004569	Valve Spring	2	1603-015703
12	100004575	Valve Spring Seat	1	1603-015705
13	100004602	Intake Valve Seal	1	1603-001572
14	100002470	Bolt, M10×1.25×87	4	
15	100011453-0003	Nut, M8	4	
16	100006373	Muffler	1	1611-018000
17	100006937	Gasket, Muffler	1	1603-018007
18	100010392	Stud, M8×48.5	2	
19	100002398	Cylinder Head	1	1611-002398
20	100009385	Spark Plug	1	
21	100011260-0005	Bolt, M6×10	1	
22	100007092	Shroud	1	
23	100010362	Stud, M6-8×127	2	
24	100005566	Gasket, Carburetor Insulator	1	1611-017107
25	100005607	Insulator	1	1611-017112
26	100005932	Gasket, Carburetor	1	1611-017182
27	100005398	Carburetor	1	1611-017100
28	100005954	Gasket, Air Filter	1	

29	100011266-0004	Bolt, M6×20	1	
30	100004711	Air Filter Assembly	1	1611-016100
31	100005013	Air Filter Base	1	
32	100004797	Gasket, Air Filter	1	
33	100004920	Muffler Sheet	1	
34	100004778	Air Filter Element	1	
35	100005079	Butterfly Nut	2	
36	100004858	Air Filter Cover	1	
37	100010817	Washer, f9×1×f16	1	
38	100011452-0003	Nut, M6	2	
39	100010219	Gasket, Cylinder Head	1	1611-009022
40	100010562	Pin, f12×20	2	
41	100004398	Push Rod	2	1611-015321
42	100004266	Tappet	2	1603-015002
43	100004529	Intake Vavle	1	1611-015701
44	100004553	Exhaust Valve	1	1611-015702
45	100003247	Piston Ring Set	1	1611-001310
46	100003221	Circlip	2	1611-013105
47	100003128	Piston Pin	1	1611-013102
48	100003088	Piston	1	1611-013101
49	100003451	Connecting Rod Assembly	1	1611-013220
50	100010028	Oil Sensor	1	1611-010028
51	100011264-0003	Bolt, M6×16	2	
52	100003844	Crankshaft	1	1611-013230
53	100010577	Woodruff Key	1	
54	100004307	Camshaft	1	1611-015100
55	100010522-0001	Washer, f16×0.5×f24	1	
56	100010681	Bearing, 6206	2	
57	100010549	Pin, f8×12	2	
58	100010157	Gasket, Crankcase	1	1611-090208
59	100003004	Crankcase Cover	1	

60	100004173-0003	Oil Plug	1	1611-014311
61	100004188	Dipstick	1	
62	100017647	Oil Seal, f30xf46x8	2	1611-017647
63	100011320-0002	Bolt, M8x35	7	
64	100004128-0003	Dipstick	1	1611-014301
65	100030561	O-Ring, Dipstick	1	
66	100008302	Governor Gear	1	1611-024620
67	100007979	Governor Gear Shaft	1	1611-024605
68	100010518-0001	Washer, f8x0.8xf20	1	
69	100017631	Oil Seal, f8xf14x4	1	1611-017631
70	100007989	Cotter Pin	1	
71	100008423	Governor Lever	1	1611-024640
72	100007956	Throttle Linkage	1	1611-024604
73	100007927	Idle Spring	1	1611-024603
74	100007878	Governor Spring	1	1611-024602
75	100011261-0004	Bolt, M6x12	8	
76	100008150	Governor Gear Bracket Assembly	1	1611-024610
77	100002688	Crankcase	1	
78	100010275	Earth Bolt	2	1611-091103
79	100010467	Washer, f12x2xf20	2	
80	100000676	Clip Base	1	
81	100010040	Oil Sensor	1	1611-010040
82		Clip	1	
83	100005137	Clamp	2	
84	100017797	Fuel Hose, f4xf8x220	1	
85	100011315-0002	Bolt, M8x25	2	
86	100008621-0006	Fuel Tank	1	1611-061100
87	100008767	Fuel Cap	1	1611-061120
88	100009314	Ignition Module	1	1611-081200
89	100011269-0003	Bolt, M6x28	2	
90	100009550	Flywheel	1	1611-082150

91	100007032	Cooling Fan	1	1611-019102
92	100007559	Starter Cup	1	1611-021520
93	100011460-0001	Nut, M16×1.5	1	
94	100007297-0006	Recoil Starter	1	1611-021500
95	100007645-0004	Blower Housing	1	
96	100007386-0004	Recoil Starter	1	
97	100010894-0001	Washer, f6	3	
98	100011565-0001	Bolt, M6×10	3	
99	100009166-0001	Stop Switch	1	1602-072380